

What do you need?

- 8 TBEI M8x10 screws
- a screwdriver

