



Call someone to help, you better be two people!

Take the cardboard template inside the seat box and put it to the ground, taking off the two base circles.

Move the two concrete bases inside the circle shapes, using the black lines as directions.

Put the seat on the bases: it is as long as the cardboard template.

Fix the seat to the bases using 8 BHSS M8X10 screws, than remove the cardboard template by breaking it.

Fix the first armrest to the seat using 4 BHSS M8X10 screws, than repeat it for the other armrest.

Finally, fix the backrest using 4 BHSS M8X10 screws.

Done!

Assembly instructions

040. Bench w/backrest+concrete

Five steps procedure

What do you need?

- 8 BHSS M8X10 screws (for the seat)
- 4+4 BHSS M8x10 screws (for the armrests)
- 4 BHSS M8x10 screws (for the backrest)
- a hex screwdriver/Allen key

