



1
Call someone to help, you better be two people!

2
Put the seat upside down on a table with soft surface in order not to damage it.

3
Take the first side and place it on the seat.
Fix it with 4 BHSS M8x10 screws.

4
Repeat the same operation with the other side of the table.

5
Finally, fix the backrest using 4 BHSS M8x10 screws.
Done!

Assembly instructions

040. Flat bench+metal sides

Five steps procedure

What do you need?

- 8 BHSS M8x10 screws (for the seat)
- 4 BHSS M8x10 screws (for the backrest)
- a hex screwdriver/Allen key

